

# TOOLKIT FOR ASSEMBLING GAS SPRINGS



## 2480.00.50.11

Toolkit for all gas springs

The toolkit contains:

Item	Order No	Term	Type
1	2480.00.50.01.001	Assembly sleeve	Mini
2	2480.00.50.01.002	Assembly sleeve	00250
3	2480.00.50.01.003	Assembly sleeve	00500
3-1	2480.00.50.01.031	Assembly sleeve (2487.12.00500.)	X500
4	2480.00.50.01.004	Assembly sleeve	00750
5	2480.00.50.01.005	Assembly sleeve	01500
5-1	2480.00.50.01.051	Assembly sleeve (2487.12.01500.)	X1500
6	2480.00.50.01.006	Assembly sleeve	03000
7	2480.00.50.01.007	Assembly sleeve	05000
8	2480.00.50.01.008	Assembly sleeve	07500
9	2480.00.50.01.009	Assembly sleeve	10000
10-1	2480.00.50.01.101	Safety ring tool	
13	2480.00.50.01.013	T-lever	M8
14-1	2480.00.50.01.141	T-lever	M16
15	2480.00.50.01.015	T-lever	G 1/8"
16-2	2480.00.50.01.162	T-lever, Extension	M6
Spare part for 16-1			
17	2480.00.50.01.017	Valve tongs	
18	2480.00.50.01.018	Valve tool	M6
19	2480.00.50.01.019	Valve tool	G 1/8"
30	2480.00.50.01.030	Valve tool	VG 5
33	2480.00.50.01.033	Valve tool (2480.00.41.1)	M6
34	2480.00.50.01.034	Disassembly handle	M3
39-1	2480.00.50.01.391	Tool case	

## Description:

Toolkit for assembling and disassembling gas springs.

## Note:

Read instructions for use before working on it.

Every tool can be ordered separately.